

# Radar/LED Speed Sign Compatibility



RADAR	2 ½-DIGIT and 3 ½-DIGIT x 8-INCH LED SPEED SIGNS	CABLE
STALKER PRO	If using the corded interface handle on the radar (with no connector on the right side): <b>Sign:</b> 1 2 3 4 5 6 7 8 ↑ ↓ ↓ ↓ ↓ ↓ ↓ ↓	155-2271-00 Radars without an RS232 port require a Handle with Data Connector, 200-0163-02.
	If using the RS232 format assembly on the radar (with connector on the right side): <b>Sign:</b> 1 2 3 4 5 6 7 8 ↓ ↓ ↓ ↓ ↓ ↓ ↓ ↓ <b>Radar:</b> Format A, 9600 baud	155-2287-25 (See note 2)
STALKER SPORT	If using the corded interface handle on the radar (with no connector on the right side): <b>Sign:</b> 1 2 3 4 5 6 7 8 ↑ ↓ ↓ ↓ ↓ ↓ ↓ ↓	155-2271-00 Radars without an RS232 port require a Handle with Data Connector, 200-0163-02.
	If using the RS232 version of the radar (with connector on the right side): <b>Sign:</b> 1 2 3 4 5 6 7 8 ↓ ↓ ↓ ↓ ↓ ↓ ↓ ↓ <b>Radar:</b> Format A, 1200 baud	155-2287-25 (See note 2)
STALKER SPORT 2	<b>Sign:</b> All switches set to OFF ↓. <b>Radar:</b> 1200 or 9600 Baud, Format A or AP, whole and tenths units	155-2287-25
STALKER SOLO 2	<b>Sign:</b> All switches set to OFF ↓ in A format. Switch 6 ↑ for bE format. <b>Radar:</b> 1200 or 9600 Baud, Format A or bE, whole and tenths units	155-2287-25
JUGS PRO-SPORTS	<b>Sign:</b> All switches set to OFF ↓. <b>Radar:</b> 1200 or 9600 Baud, Format A or bE, whole and tenths units	155-2287-25
STALKER PRO II	<b>Sign:</b> All switches set to OFF ↓ in A format. <b>bE Format:</b> 1 2 3 4 5 6 7 8 ↓ ↓ ↓ ↓ ↓ * * * For Release Speed ↑ ↓ ↓ For Plate Speed ↓ ↑ ↓ For Hit Speed ↑ ↑ ↓ <b>Radar:</b> 1200 or 9600 Baud, Format A or bE, whole and tenths units	155-2284-00
	<b>Sign:</b> All switches set to OFF ↓ in A format. <b>bE Format:</b> 1 2 3 4 5 6 7 8 ↓ ↓ ↓ ↓ ↓ * * * For Release Speed ↑ ↓ ↓ For Plate Speed ↓ ↑ ↓ For Hit Speed ↑ ↑ ↓ <b>Radar:</b> 1200 or 9600 Baud, Format A or bE, whole and tenths units	
STALKER ATS II	<b>Sign:</b> All switches set to OFF ↓ in A format. <b>bE Format:</b> 1 2 3 4 5 6 7 8 ↓ ↓ ↓ ↓ ↓ * * * For Release Speed ↑ ↓ ↓ For Plate Speed ↓ ↑ ↓ For Hit Speed ↑ ↑ ↓ <b>Radar:</b> 1200 or 9600 Baud, Format A or bE, whole and tenths units	155-2284-00
	<b>Sign:</b> All switches set to OFF ↓ in A format. <b>bE Format:</b> 1 2 3 4 5 6 7 8 ↓ ↓ ↓ ↓ ↓ * * * For Release Speed ↑ ↓ ↓ For Plate Speed ↓ ↑ ↓ For Hit Speed ↑ ↑ ↓ <b>Radar:</b> 1200 or 9600 Baud, Format A or bE, whole and tenths units	
JUGS Si Arcade	<b>Sign:</b> All switches set to OFF ↓. <b>Radar:</b> 1200 or 9600 Baud, defaults to 1200.	155-2312-20
STALKER Speed Sensor*	<b>Sign:</b> All switches set to OFF ↓ in A and AF format. <b>Sensor:</b> 1200 or 9600 Baud, Format A or AF, whole and tenths units	155-2315-30
STALKER Pro II Speed Sensor*	<b>Sign:</b> All switches set to OFF ↓ in A format. <b>bE Format:</b> 1 2 3 4 5 6 7 8 ↓ ↓ ↓ ↓ ↓ * * * For Release Speed ↑ ↓ ↓ For Plate Speed ↓ ↑ ↓ For Hit Speed ↑ ↑ ↓ <b>Sensor:</b> 1200 or 9600 Baud, Format A or bE, whole and tenths units	155-2315-30

\* RS-232 models only

Notes: 1. The standard cable length for all signs is 20 feet unless otherwise noted. Longer cable lengths are available.  
2. Requires a Battery Handle (200-0480-00) or Corded Handle (200-0163-00).

**STALKER**<sup>®</sup> Sports Radar

The World Leader in Sports Speed Measurement  
applied concepts, inc.

2609 Technology Drive ■ Plano, Texas 75074  
972.398.3780 ■ Fax 972.398.3781

**StalkerSportsRadar.com**



**888-STALKER**