



## MC 360 | Optional Remote Access


# Remote Access to your Stalker Message Center 360

Developed specifically for law enforcement agencies, the Shield Communications Plan gives users cellular access capabilities, including downloading radar data. The message board's functionality is controlled from a desktop or mobile phone without the need to send officers to the location. This time-saving option is now available with all new Stalker MC360 variable message signs.



### Powerful Remote Features

- Change message or graphics on one board, or a group of boards simultaneously
- View minute-by-minute battery voltage reports
- Set schedules and alerts
- Dual radar modes
  - Speed Enforcement Mode
  - Data Collection Mode
- Retrieve and download traffic data
- Store messages and graphics in a common library
- Set Geofencing




# STALKER®

## Power to Enforce.


StalkerRadar.com




Simple user-friendly interface



Minute by minute battery voltage reports




Built in traffic data reporting



Quick and easy GeoFencing

## Intuitive Interface

In this modern age of policing, the days of requiring an officer to drive from message board to message board to update, download data, or check battery voltage are over. Now, with a connected Stalker Message Center 360, the locations of all connected message boards are displayed on an intuitive map interface.



## Remote Updates of Messaging and Graphics

Through the use of floating pallets, message and graphic updates can be quickly executed. All functions of the message board are accessed with a few clicks of a mouse. Font size, display timing, and radar operations can be updated and scheduled on demand. Often used messages and graphics can be saved to a common library for efficient recall. Minute-by-minute battery voltage reports help to monitor key message board systems.

## Switch Radar Modes

### Speed Enforcement Mode

Also called Police Mode, a full range of speed detection functions are available. Minimum speed messaging, maximum speed messaging, and violator speed messaging are controlled by the intuitive interface.

### Data Collection Mode

Also called Legacy Mode, a trip speed is set with the corresponding messaging and scheduling functions.

### Download Traffic Data

Remote download of your traffic data is an important function of the interface. Management of data can be done directly through the interface, or imported into the Stalker Easy Analyst software for interpretation and reporting.

## Set GeoFence

A GeoFence, or virtual boundary, sets triggers for an email or text message alert once the unit leaves the boundary. This is a useful tool for security and custom travel time functions.

StalkerRadar.com

**STALKER**<sup>®</sup>

**Power to Enforce.**

applied concepts, inc.  
855 East Collins Boulevard ■ Richardson, Texas 75081  
972.398.3780 ■ Fax 972.398.3781



006-0612-00 Rev A

Copyright © 2019 Applied Concepts, Inc. All Rights Reserved. Specifications are subject to change.

**800-STALKER**