

# Quick Reference

# T5 THERMAL



1500-Lumen search lights

Tactical sling attachment

12 VDC Charger port

USB port

High-output LED emitters for night vision

High-resolution Color CCD 540 LOR camera

High-sensitivity microphone

110 dB siren activation

Strobe light activation

Zoom adjustment

Focus adjustment

**FLIR**  
Powered by FLIR® Core

High-powered Color Thermal Imaging Camera

110 dB siren

**Warning:** Do not plug any charger into the charging port other than the one provided.

**Note:** Only the USB cable provided with the T5 Thermal® will work with the unit. A Standard USB cable will produce an error message.

StalkerRadAr.com

# STALKER®

## Power to Enforce.



**Temperature Scale:**

The base temperature scale is 0-300 degrees, but this scale will expand to 0-1000 degrees when the mean temperature of the view exceeds 300 degrees for a preset period of time.



The memory card ICON will turn red to let you know when it is almost full.



Empty - 25%



25% - 75%



75% - Full

**Surface Temperature Read Out:**

The surface temperature readout is indicated live in the lower left of the display. The blue retical in the center of the display is the point at which the temperature is calculated.

**Image adjust:**

Press IN on LEFT joystick then LEFT or RIGHT

**Record Mode:**

Press the RIGHT joystick to the RIGHT to start and stop a video recording

**Menu Mode:**

Press and hold LEFT joystick UP for 5 seconds to enter Menu mode

**Image Capture:**

Press RIGHT joystick to the LEFT to take a snapshot

**T5 Thermal Color Palette (on color model) and Camera Select Switch:**

**Camera Select:**


Press DOWN to toggle between the Thermal and CCD cameras.

**Zoom:**

Press LEFT to toggle between 1X, 2X, and 4X Zoom when in Thermal Mode.

**Palette Select:**

Press UP to toggle between the 14 different color palettes when in Thermal Mode. The T5 Thermal boots up in the standard White Hot palette.




**Flood light:**

Press and release to turn ON / OFF



**Main power:**

Press and release to turn ON / OFF



**NOTE:** The T5 Thermal has a recording time limit of one hour per video. After the hour is complete, the file is saved and a new recording starts immediately without any additional commands from the user.

StalkerRadar.com

**STALKER®**

**Power to Enforce.**

applied concepts, inc.  
2609 Technology Drive ■ Plano, Texas 75074  
972.398.3780 ■ Fax 972.398.3781



011-0175-00 Rev A

**800-STALKER**