

# STALKER® ENHANCED DUAL DSR SPECIFICATIONS

## General Specifications

CE Approved

Type:	Dual Antenna Direction Sensing Moving/Stationary Doppler Radar													
Operating Frequency:	33.4 GHz - 36.0 GHz (Ka-Band)													
Stability:	$\pm 100$ MHz (Ka-Band)													
Power Requirements: (With 2 Antennas)	10.0 to 16.4 VDC. (currents are typical at 13.6 VDC): XMIT with all displays on: 1.28A XMIT with all displays off: 1.08A XMIT with moving target: 1.15A XMIT with no target: 1.11A Standby with no target: .8A													
Total Power Consumption:	1.28 A													
Environmental:	-30° to +70° C, 90% Relative Humidity Operating -40° to +85° C, non-operating													
Display:	Triple (red, green, amber) 3-digit Light Emitting Diode (LED) for target, lock, and patrol, plus LED icons													
Mechanical:	<table> <tr> <td><b>Display Unit</b></td> <td>Weight - 0.5 lb.</td> <td>Size - 1.65" Height, 1.05" Depth, and 5.50" Width</td> </tr> <tr> <td><b>Counting unit</b></td> <td>Weight - 1.6 lbs.</td> <td>Size - 1.65" Height, 3.90" Depth, and 5.50" Width</td> </tr> <tr> <td><b>Antenna</b></td> <td>Weight - 1.4 lbs.</td> <td>Size - 2.50" Dia. X 4.75" Length</td> </tr> <tr> <td><b>Remote</b></td> <td>Weight - 0.4 lb.</td> <td>Size - 1.00" Height, 6.20" Length, and 2.25" Width</td> </tr> </table>		<b>Display Unit</b>	Weight - 0.5 lb.	Size - 1.65" Height, 1.05" Depth, and 5.50" Width	<b>Counting unit</b>	Weight - 1.6 lbs.	Size - 1.65" Height, 3.90" Depth, and 5.50" Width	<b>Antenna</b>	Weight - 1.4 lbs.	Size - 2.50" Dia. X 4.75" Length	<b>Remote</b>	Weight - 0.4 lb.	Size - 1.00" Height, 6.20" Length, and 2.25" Width
<b>Display Unit</b>	Weight - 0.5 lb.	Size - 1.65" Height, 1.05" Depth, and 5.50" Width												
<b>Counting unit</b>	Weight - 1.6 lbs.	Size - 1.65" Height, 3.90" Depth, and 5.50" Width												
<b>Antenna</b>	Weight - 1.4 lbs.	Size - 2.50" Dia. X 4.75" Length												
<b>Remote</b>	Weight - 0.4 lb.	Size - 1.00" Height, 6.20" Length, and 2.25" Width												
Accuracy:	+1, -2 mph stationary, ±2 mph moving +2 / -3 km/h stationary, ±3 km/h moving													
Automatic Self-Test:	Performed every 10 minutes													
Stationary Speed Range:	12 mph to 200 mph Standard or 2 mph to 200 mph (set-up menu selectable) <b>Stationary Fastest Speed</b> - Same speed range as stationary speed													
Moving Speed Range:	<p><b>Patrol speed</b> – Once acquired, will track to 150 mph. Acquisition speed is selectable with <b>P.S. 5/20</b> key.            5 in patrol window for patrol speed acquisition speeds of 5 to 90 mph;            10 in patrol window for patrol speed acquisition speeds of 10 to 90 mph;            20 in patrol window for patrol speed acquisition speeds of 20 to 90 mph</p> <p><b>Opposite lane target speed</b> – 200 mph Max closing            For 5 mph patrol speed: 20 mph to 195 mph; For 70 mph patrol speed: 35 mph to 130 mph.</p> <p><b>Opposite lane Fastest Speed</b> – Same speed range as opposite lane speed</p> <p><b>Same lane target speed</b> – Related to patrol speed: ±70% of patrol speed within 5 mph of patrol speed. For 50 mph patrol speed: 15 → 45 mph and 55 → 85 mph.            Same lane patrol speed must be greater than 15 mph</p>													

## Microwave Specifications

Antenna:	Conical horn with corrective lens
Antenna gain:	22 db
Polarization:	Circular
3 db Beam width:	12° ±1°
Microwave Source:	Gunn-Effect diode
Antenna Receiver Type:	Two Direct Conversion Homodyne receivers using four low-noise Schottky barrier mixer diodes
Power Output:	10 mW minimum 25 mW nominal 50 mW maximum Radiated Output Power, 1.0 db. (Radiated output power does not change more than +/- 1.5 db when the source power changes +/- 20%.)
Power Density:	2 mW/cm² maximum at 5 cm from lens

## Display Messages

PASS:	PASS spelled out in display with a 4-beep "happy" tone indicates the unit has just passed self-test.
FAIL:	FAIL spelled out in display with a 15-beep tone indicates a circuit malfunction has been detected, in which case speed readings are inhibited. Remove the unit from service and repair. FAIL will remain on the display until reset by being powered off.

[ ], SC, SA, or S_:	Indicates the radar mode of operation in the patrol speed window. [ ] or a speed display in the patrol window indicates moving mode radar operation. <b>SC</b> indicates stationary operation with display of closing targets only. <b>SA</b> indicates stationary operation with display of targets proceeding away from the radar unit. <b>S_</b> is a mode for stationary operation which allows the display of targets in both directions.
<b>SEn 1, SEn 2, SEn 3 or SEn 4:</b>	<b>SEn 1</b> thru <b>SEn 4</b> is used to indicate the current range (sensitivity) setting . <b>SEn 1</b> is minimum; <b>SEn 4</b> is maximum. Opposite lane sensitivity is independent of same lane sensitivity. They are separately set.
<b>5 or 20:</b>	<b>5, 10, or 20</b> spelled out in the patrol window indicates the low-end patrol speed is set to either 5 mph, 10 mph, or 20 mph
<b>Aud 0, Aud 1, Aud 2, Aud 3, or Aud 4:</b>	<b>Aud 0</b> thru <b>Aud 4</b> spelled out on the display unit indicates the current speaker volume setting. <b>Aud 0</b> is off; <b>Aud 4</b> is loudest.
<b>b 0, b 1, b 2, or b 3:</b>	These symbols are spelled out in the Patrol Speed display during the time that the audio number (Aud 3) is shown in the Target and Lock displays. The b number indicates the beep volume and is accessed by using the <b>P.S. BLANK</b> key.
<b>U 0, u 1, u 2, or u 3</b>	These symbols are spelled out in the Patrol Speed display during the time that the audio number (Aud 3) is shown in the Target and Lock displays. The <b>u</b> number, when displayed, indicates the state of the voice volume and is accessed by using the <b>SQL</b> key.
<b>bri 1, bri 2 bri 3, bri 4, bri 5, or bri 6:</b>	Used to indicate display brightness. <b>bri 1</b> is the dimmest; <b>bri 6</b> is the brightest.
<b>Hot:</b>	The display flashes <b>Hot</b> and powers down when the internal temperature exceeds specifications. Automatically resumes operating when the temperature drops.
<b>rFI:</b>	<b>rFI</b> is displayed in the Target window indicating the presence of an interfering signal. Operation is inhibited during an <b>rFI</b> indication.
<b>Ulo:</b>	<b>U Lo</b> is displayed in the Target window when the input voltage falls below approximately 8 volts. Operation is inhibited, but normal operation will resume automatically when the input voltage is restored to a normal voltage (>9.0 volts).

## Remote Control Functions

<b>STRONG LOCK/REL</b>	The <b>STRONG LOCK/REL</b> key alternates between the lock and the release functions for the strong target. <b>LOCK</b> is used to transfer the contents of the target window to the lock window. <b>REL</b> clears the locked contents of the lock window and the patrol window. During lock, the patrol window will lock the present patrol speed and the <b>LOCK</b> icon will light. The target window and Doppler audio remain active after lock.
<b>ANT:</b>	Used to switch between the front and rear antenna. The <b>FRONT</b> or <b>REAR</b> icon will light. A 1-beep tone corresponds to the front antenna while a 2-beep tone corresponds to the rear antenna. The counting unit can sense the presence or absence of either antenna.
<b>XMIT/HOLD:</b>	Toggles between xmit and hold (standby). The <b>XMIT</b> icon will light.
<b>MOV/STA:</b>	Sequences between Moving mode and three stationary modes of operation: targets closing only, targets away only and targets in either direction.
<b>SAME/OPP:</b>	The <b>SAME/OPP</b> key is used to alternate between same lane moving mode and opposite lane moving mode. The <b>SAME</b> icon toggles on and off to indicate same lane mode.
<b>FAST LOCK/REL</b>	The <b>FAST LOCK/REL</b> key alternates between the lock and the release functions for the fast target. <b>LOCK</b> is used to lock the contents of the fast window and <b>REL</b> clears the locked contents of the fast window. During fast lock, both the <b>FAST</b> icon and the <b>LOCK</b> icon will light and the patrol window will lock the present patrol speed. The target window and Doppler audio remain active after locking.
<b>STOPWATCH MODE:</b>	Toggles the unit from radar mode to stopwatch mode and back again.
<b>S/S:</b>	In Stopwatch Mode, the S/S (or START/STOP) key is used to start and stop the electronic timing of the target vehicle as it enters and exits the speed measurement zone.
<b>100:</b>	In stopwatch mode, this key can be used to change the timing distance in 100 yard increments.
<b>10:</b>	In stopwatch mode, this key can be used to change the timing distance in 10 yard increments.
<b>1:</b>	In stopwatch mode, this key can be used to change the timing distance in 1 yard increments.
<b>SEn:</b>	Used to adjust the range (sensitivity) at any time. Maximum sensitivity is <b>SEn 4</b> ; minimum sensitivity is <b>SEn 1</b> . Opposite lane sensitivity is independent of same lane sensitivity. <u>They are separately set.</u>
<b>SQL:</b>	The <b>SQL</b> key toggles the squelch override off and on. In the normal (off) position, audio will only be heard when a target is being tracked. When the Doppler audio menu is displayed, this key can be used to change the voice volume.
<b>PS 5/20:</b>	Used to select a low-end patrol speed of either 5 mph, 10 mph, or 20 mph. For example: <b>5</b> in patrol window for patrol speed acquisition of 5 to 90 mph <b>10</b> in patrol window for patrol speed acquisition speeds of 10 to 90 mph; <b>20</b> in patrol window for patrol speed acquisition of 20 to 90 mph
<b>SELF TEST:</b>	In radar operation, performs a complete self-test on display/counting unit and the <u>selected</u> antenna. The display unit shows speeds of <b>10, 35, and 65</b> ; temperature inside the display/counting unit in °F (e.g., <b>110</b> )

	•F); and input battery voltage (e.g., bAt 13.8); followed by "PASS" and a 4-beep "happy" tone or "FAIL" and a 15-beep tone. At the end of a successful test, the <b>FORK</b> icon is lit on the display to allow a measurement of non-directional speeds such as that produced by a tuning fork.
	Used to adjust the volume of the Doppler audio up or down. <b>Aud 0</b> is off; <b>Aud 4</b> is loudest.
<b>P.S. BLANK:</b>	In radar operation, this is a three function key. Used to re-acquire patrol speed. Also, blanks the patrol speed after a target speed and patrol speed are locked. Pressing the <b>P.S. Blank</b> key again restores the blanked speed. When the Doppler audio menu is displayed, this key can be used to change the beep volume.
	Dual function key. A single depression of the  key activates the keyboard backlight for six (6) seconds. Two rapid depressions of the  key activates the display brightness control. Additional depressions of the  key toggles the display unit's brightness from bri 1 (low) to bri 6 (high).